

## MP3 Spelare

400-1520	MP903 MP3 player Portable 20GB	10 700,00
400-2610	NanoPlayer OEM card, 1in, IR,	1 960,00
400-2620	Monteringsram Nano/Geo player	235,00
400-2615	GeoPlayer OEM card, GPS	3 940,00
400-2620	Monteringsram Nano/Geo player	235,00
400-2625	GPS ant, magnet 5m kabel MMCX	535,00
400-2710	AP103 MP3 spelare 12V/6W	2 940,00
400-2720	AP103+ MP3 spelare 12V/40W	3 230,00
400-2790	Racktray 19" 1U MicroPlayer	385,00
400-2510	SP203 MP3 spelare utan HDD	4 910,00
400-2040	AP303 MP3 player, 8in / 16rel.	10 800,00
400-2210	EventPlayer MP3/WAV player	6 870,00
400-2790	Racktray 19" 1U MicroPlayer	385,00

## Digital Signage

400-4012	Flash MPX HD Video/Audio play.	5 890,00
400-4020	VP100HD Player Loop	4 710,00
400-4030	VP100HDi Player Interactive	6 680,00

## 230VAC Styrning

400-2790	Racktray 19" 1U MicroPlayer	385,00
400-2805	MicroSwitch 230VAC switch	1 760,00

## Fjärrstyrning

400-2810	SensoPad switch	580,00
----------	-----------------	--------

## Högtalare special

400-2920	Vibro Glass surface speaker	1 760,00
----------	-----------------------------	----------

## Rackmonteringskit

400-2620	Monteringsram Nano/Geo player	235,00
400-2630	Rackmontage för 4 Nanoplayer	385,00
400-2620	Monteringsram Nano/Geo player	235,00
400-2635	Rackmontage för 15 Nanoplayer	710,00